

ENGINE OIL DRAIN VALVE - PASSENGER CARS/LIGHT TRUCKS
09/30/2010

IMPORT VEHICLES		PART #
Alfa Romeo	All models	FG7B
Audi	80/80 Quattro('88-'92), 90/90 Quattro('88-'91), 100/100 Quattro('89-'91), 200/200 Quattro('89-'91)	F-106
	90/90 Quattro('90-'91 20 valve), 100/100 Quattro('92-'94), 200 Quattro('90-'91 20 valve)	T-207
	V8 Quattro('90-'94), A8/A8 Quattro('97-on)	FG-8
	S4('92-'94), S6('95-'97), Cabriolet('94-'98), A4/A4 Quattro(4 cyl.-upto '95), A6/A6 Quattro('95-'96)	T-207
	99 & on A4/A4 Quattro(4cyl.) & TT(1.8L Turbo) -- Requires adapter ADP-207 due to recessed plug	T-207
	S4('00-on), S6('01-on), A4/A4 Quattro(V6), A6/A6 Quattro('97-on), Allroad('01 & on)	F-106
All other models	F-106	
Acura	All 4 cyl. engines ('96 & on oil pans with recessed plug require adapter ADP-106)	F-106
	All V6 engines('99 & on oil pans with recessed plug require adapter ADL-106)	F-106
BMW	All models up to 1980	FG7B
	All models from 1981 & on (oil pans with recessed plug require adapter ADP-109)	F-109
Fiat	All models	FG7B
Honda	All models up to 1983	F-105
	98 & on, Accord(4cyl.), Prelude & S2000 require adapter ADP-106	F-106
	96 - on V6 engines require adapter ADL-106, Civic I VTEC engine requires adapter ADL-106	F-106
	All other models from '84 & on	F-106
Hyundai	All models	F-106
Infiniti	All models	F-103
Isuzu	2x4 Pup engines & 4BD1 truck engines	F-105
	89 - '91 Trooper II	F-107
	All other engines	F-106
Jaguar	98 & on, V8 engines	F-106
	2000 & on, V6 3.0L engine	F-107
Kia	All models. (2000 - on models require adapter ADP-106)	F-106
Land Rover	99 & on, all models	F-106
Lexus	All models	F-103
Mazda	90 to '95 All Miata engines. Miata w/1.8L, MX-5, Mazda3 w/2.0L, Protege5 w/2.0L. ADP-106 required.	F-106
	Mazda3, Mazda5, Mazda6, CX-7, Tribute, Tribute Hybrid w/2.3L DOHC ADP-106 required.	F-106
	All models with V6(24 valve) engines(Tribute, Millenia, Mazda6, MPV, CX-9)	F-107
	07 & on Mazda6 3.0L, CX-9 3.5L /3.7L 24valve engines ADP-107 Required	F-107
RX-8 ADL-106 required	F-106	
Mercedes	560SEL, 560SEC, 500SEL, 500SEC, 450SEL, 420SEL, 400E, 380SE, 300SD, 300D(up to '85)	F-109
	300TD(up to '85), 300CD, 240D, 280E, 280CE, 280SE, 190D(2.2-up to '84), 190E(2.3-up to '84)	F-109
	560SL, 450SL, 450SLC, 380SL, 380SLC	T-207
	350 SDL, 300TE, 300SDL, 300SE, 300SEL, 300D('87), 300TD('87), 300CE, 300E, C280, 260E	F-106
	190E(2.6 & 2.3 - 16), 190E(2.3 - '85 to '93), 190D(2.5), 190D(2.2 - '85 to '89)	F-106
	All other models from '86 & on	F-106
Mini Cooper	07 & on, all models	F-108
	02 - '06, all models	F-106
Mitsubishi	All models('01 & on Montero requires adapter ADL-106)	F-106
Nissan	All models from 1990 & on	F-103
	Sentra('83 & on), Pulsar('83 & on), 200SX('84 & on), Gas trucks, 300ZX, Maxima('85 & on)	F-103
	Stanza Wagon('86 & on)	F-103
	All other models(up to '89)	F-102
Peugeot	505 Gas Turbo	F-105
	307XS	F-106
	All other models	F-108
Porsche	911(All), 928(up to '81), 930(up to '77)	FG7B
	928('82 & on), 930('78 & on), 944(All)	F-105
	924	T-207
	912E, 914	F-109
	Boxter('97 & on)	F-104
Renault	All models	F-108
Saab	All models (except GM engines: F-107, Subaru engines: F-105)	F-106
Scion	All models	F-103
Subaru	2010 & on Outback 4 cyl	F-108
	All models	F-105
Suzuki	07 - '09, XL-7 with GM engine	F-107
	All other models	F-106
Toyota	All models from 1993 & on	F-103
	85 & on Tercel, Celica, MR2, Gas Corolla, Gas trucks	F-103
	Van('86 & on), Camry('88 & on), Land Cruiser('87 August & on)	F-103
	Land Cruiser(up to '81)	FG-5
	Land Cruiser('82 to '87 July), & all other models	F-104
VW	Eurovan ('92 - '99 4 cyl., 5 cyl. Gas/Diesel engines)	T-207
	98 - '99 1.8L Turbo(Passat) --- Requires adapter ADP-207 due to recessed pan	T-207
	Touareg(V8, V10 engines), Phaeton(V8 engine)	FG-8
	All other water cooled engines('99 & on oil pans with recessed plug *require adapter ADP-106)	F-106
Volvo	All 4 cylinder engines. Other engines up to '75	T-204
	6 cylinder engines('76 - '82)	F-108
	6 cylinder engines('83 & on). Diesel Turbo engines	F-104
	5 cylinder engines. (engines with recessed plug require adapter ADP-104)	F-104

Adapter required for oil pans with recessed oil plug. For N-series(with nipple) add letter "N" to the part # (i.e. F-101N)